




41960 TURBOCHARGER

Dimensions shown as Width x Depth x Height. Specifications are correct at time of printing and are subject to change without notice.
LHF - left hand facing RHF - right hand facing IA - inside arm to inside arm For SKU options: R=Manual Recline, E=Power Recline



1R Manual Recliner
36 x 37 x 41"
91 x 94 x 104cm
IA: 22" / 56cm



2R LHF Arm, Man
Recliner
30 x 37 x 41"
76 x 94 x 104cm



3R RHF Arm, Man
Recliner
30 x 37 x 41"
76 x 94 x 104cm



4R Armless Loveseat
Man Recl
47 x 37 x 41"
119 x 94 x 104cm



5R LHF Arm, RHF
Wedge, Man Recl
41 x 37 x 41"
104 x 94 x 104cm
IA: 22" / 56cm



6R RHF Arm, LHF
Wedge, Man Recl
41 x 37 x 41"
104 x 94 x 104cm
IA: 22" / 56cm



7R RHF Wedge, Man
Recliner
36 x 37 x 41"
91 x 94 x 104cm



8R Armless Manual
Recliner
23 x 37 x 41"
58 x 94 x 104cm



9R LHF Wedge, Man
Recliner
36 x 37 x 41"
91 x 94 x 104cm

Dimensions

A - Seat Depth - 22.5" / 57cm

B - Seat Height - 20.5" / 52cm

C - Arm Height - 25" / 64cm

Features

- Chaise styling for ultimate comfort and support in full recline
- Hardwood, softwood and engineered wood products; all joints pinned & glued for uniformity & strength
- Back: Premium elastic webbing offers consistent suspension for the life of the product
- Seat: 8 gauge sinuous wire springs for superior ride and comfort
- Seat Fill - 1.8 lb high resilience foam for superior comfort without loss of support
- Back Fill- Foam filled back cushions
- Toggle Switch for power operation
- LED cupholder switch for power operation

Options

- Stainless Steel Cupholder
- Antique Cupholder
- LED cupholder with groundlighting
- Wireless Bass Shaker
- Wood or aluminum foot



41960 TURBOCHARGER

Popular Configurations

Note: Always assemble configurations from right hand facing to left hand facing components.

How We Measure

Height - measured from the highest point of the back pillow to the floor.

Depth - measured from the front edge of the seat cushion to the top of the back.

Width - measured from the widest point of the arm or arm pillow to the widest point of the opposite arm or arm pillow.

Arm Height - measured from the top of the arm to the floor.

Seat Height - measured from the crown of the seat cushion to the floor.

Warranty

Wood Frames, Springs or Webbing - ten year warranty


Metal Frames - two year warranty under normal household use

Motion Reclining Mechanisms - seven year warranty

Reclining Chairs, Sofabed Mechanisms and Sofabed Mattresses - two year warranty

Seat Cushion Foam and Fibre-filled


Components - five year pro-rated warranty



2-Seat Straight HTS

66 x 62"


168 x 157cm



2-Seat Curved HTS

71 x 64"


180 x 163cm



3-Seat Straight HTS

95 x 62"


241 x 157cm



3-Seat Curved HTS

107 x 66"


272 x 168cm



4-Seat Straight HTS

124 x 62"

315 x 157cm



4-Seat Curved HTS

142 x 68"

361 x 173cm